

Fusion720 Inline wrapper Diagnostic procedure



- Loading section roller
 - Lower position of loading section roller (M)
 - Upper position of loading section roller (N)

The sensor (M) and (N) are use primarily during the individual wrapping mode, in order to inform the computer if the loading section roller is fully extended out, or fully retracted in.

Like all other sensor, the head flat face of the sensor shall be install so it is about $\frac{1}{4}$ inch away from the carriage which move up and down.

