

## Quick setting TAC-08C & remote control

2013 and before

Setting quick reference



To switch from MENUS mode to programming adjustment mode (or vice-versa), simultaneously press the buttons [+] and [-], then release.

### **ADJUSTMENT 1:** Maximum number of revolutions to wrap a bale.

Change the number as necessary with button 3 or button 4 according to the instructions given in the windows. Adjust your number of revolutions according to the size of the bale and forage characteristics. To move on to the next adjustment, press the [+] button on the remote control.

### **ADJUSTMENT 2:** Maximum RPM of the turntable.

If the oil flow from the tractor is insufficient (without power unit), the turntable will not reach the maximum desired RPM (see MENU #3). It will also not stop properly and will have to slow down. Additionally, to protect itself, the table will automatically reduce its RPM and bale wrapping performance will decrease.

**Solution:** Increase oil flow from the tractor or decrease the maximum RPM desired for the table with button 3 or button 4 of the current adjustment.

### **ADJUSTMENT 3:** Number of bales wrapped in the day.

If desired, reset to zero each new day with button 3.



## Quick setting TAC-08C & remote control

2013 and before

Setting quick reference

**ADJUSTMENT 4:** Choice of machine model: 680, 780SB $\frac{1}{4}$ , or 780SB.

If your machine is a 780SB, choose the 780SB model. If you want to load your bales using a tractor at the side of the bale wrapper instead of at the rear, you must choose mode 780SB $\frac{1}{4}$  instead of 780SB, and the table will turn an extra 90° at the end of its cycle. (600=680, 680 +loading arm=780SB +1/4...)

**ADJUSTMENT 5:** Automatic stop when plastic film roll ripped or empty.

Activate or deactivate this sensor mechanism on the plastic film stretcher with button 4 [yes / no ]. Note that you must deactivate this command if you want to manually test the machine without a bale, because the machine will automatically stop after a quarter revolution due to lack of plastic film.

**ADJUSTMENT 6:** User language.

Choose French or English with button 4.

**ADJUSTMENT 7:** Remote control contrast.

To accentuate or not the writing of the messages in the windows. This may be useful on a sunny day. Adjust using buttons 3 and 4 according to the instructions provided by the windows.

**ADJUSTMENT 8:** Zeroing the turntable.

To reach this menu, alignment must first have been performed. If the position of the table before unloading needs to be better adjusted (the table in unloading position must be as perpendicular as possible to the bale wrapper frame), push button 3 or button 4: [- ] or [ + ]. You will have a choice from -5 to +5. Press button 2 [Activate] and observe the result obtained. Readjust if necessary.

**ADJUSTMENT 9:** To associate the TAC-08C.

See **A-IND-002 Association of the remote control**