


## Black wire (starter) connection



**A-** Black wire connected to the starter

If you are having problem with the start of the Honda engine, verify that the black wire is properly connected at the back of the engine's starter (A).