

PROCEDURE REF# A-IND-064

Bleeding the gas line (auxiliary tank)

When passing from the Honda gas tank to the auxiliary one (6 gallons), it may take a few seconds to make the engine runs if there is air in the pipe. If it does not start at all, follow the next steps to make it run.

1. The 3 positions gas valve should already set toward the left (A).
2. With the Honda key, try to start the engine with choke for a few seconds. If it does not start yet, follow the next step.
3. Try to start again with 2 crank start. Thereby, it should start up. Repeat if needed.



The job is done!

Required time:

- 15 minutes

Required tools:

- None