

# PROCEDURE



## IG-D2 ASSOCIATION

If the Honda engine don't start when using the remote stop and start of the IG-D2 option. Try to associate the remote. First turn off the Honda engine key to the OFF position. Hold the bottom button (Stop) and while holding it turn the Honda engine key to the ON position and then OFF and then to ON again. Release the bottom button (Stop) and now you should be able to start the engine with the top button (Start). (IT CAN TAKE MORE THAN ONE TRY TO HAVE IT WORK)



If it don't work make sure the connector of the IG-D2 box is well connected on the Honda engine wiring and make sure the connector are free of water or humidity.



## PROCEDURE



## IG-D2 TROUBLESHOOT

If you want to make sure that the problem is getting from the IG-D2 box and/or remote. You can unplug the IG-D2 box and use a jumper wire to connect the 2 top pin of the connector (shown is yellow in the picture below) The motor should start. If it start then the problem come from the IG-D2 box or remote. If its not starting then the problem might be the connector or the red and orange wire been not well connected (shown in picture below).

