


PROCEDURE REF# A-IND-026



Spring for mechanical cut & hold

You can adjust the spring of the cut & hold (only if needed) as you see in the photo.



Note: Lubrication is very important for the cut & hold to work properly.