

## Error #26

### Hydraulic pressure too high

Error #26 means that something is causing too much resistance for a well functioning of the moving components.

When the hydraulic pressure reaches 2500 PSI during a minute, the error code will notify, and you must make these verifications:

1. Verify that the 3 points hitch (stabilizer arms) is not too low.
2. Make sure that the top link adjust well the gap between the ground and the unit.
3. Make sure that the skids are well positioned.
4. The operation speed may be too high compared to the picked-up crop.
5. The windguard is locked and creates heaps. Unlock as in the below picture.
6. Verify if there is accumulation in the rotor.
7. Verify if there is accumulation in the conveyors.

