


THE DISPLAYED WEIGHT STAYS TO ZERO

Even if you load or unload some components in the mixing chamber, the displayed weight stays to 0 or on a value, a load cell could be defective. Follow these steps in order to reach the broken one.

1. Turn on the monitor by pressing on the  key;
2. To the Connexion Box (900702), unplug the first connector of your choice with a Phillips screwdriver;
3. Verify if there is a displayed weight. If yes, (even if it's not the right weight), this load cell is good;
4. To the Connexion Box (900702), unplug the second connector of your choice with a Phillips screwdriver. Repeat the step 2 & 3 until the weight displays 0;
5. The weight displayed is 0, this correspond to the broken load cell, replace it.

Needed tool:

- Phillips screwdriver