

REPLACING PTO SHEAR BOLTS

- 1- Disengage the PTO, turn off the tractor and uncouple the drive shaft.
- 2- Remove the broken pieces of shear bolts from the yoke (A).
- 3- Insert the new shear bolt (refer the operator manual to know what size of shear bolt each model of mixer require)
- 4- Put the drive shaft back in place.

